

WILKINSON HEAVY PRECAST LTD.

The inspection & maintenance details for Three Compartment Oil/Sediment Interceptors are as follows;

Visual inspection of all three (3) compartments must be done monthly.

- Oil accumulation that is greater than 300mm thick in any chamber must be removed
- Sediment accumulation that is greater than 300mm deep in any chamber must be removed
- Any floatable debris that has been collected can be removed when Oil and Sediment is removed

All three (3) compartments should be completely cleaned once per year. Visual inspection of the internal components (Trash racks, Elbows, etc.) is to be done once a year.

If and when a spill occurs, the oil/contaminant must be removed immediately after it has been contained by the interceptor.

Note: This is a guide for regular maintenance of the Interceptor. Frequency of these inspections/cleanings will change depending on the amounts of contaminants that are collected. These inspections/cleanings are the responsibility of the owner who must ensure that the Interceptor is properly maintained at all times.

Please contact me if you have any questions.

Thank you



MATT WILKINSON